


Smarty 2X P/3X P/4X P

- In order to remove the filters, open filter cover by pulling the strap and take out the filters.
- Use Coarse 65% (G4) filters or optionally the ePM1 70% (F7) filter for outdoor air filtration and the Coarse 65% (G4) filter for the exhaust air filtration.



Standard filters:

- Filter panel cardboard frame MPL Z 185x168x25-Coarse-65 (G4) (Smarty 2X P)
- Filter panel cardboard frame MPL Z 225x195x25-Coarse-65 (G4) (Smarty 3X P/ Smarty 4X P)

Optional filters:

- Filter panel cardboard frame MPL 185x168x25-ePM1-70 (F7) (Smarty 2X P)
- Filter panel cardboard frame MPL 225x195x25-ePM1-70 (F7) (Smarty 3X P/ Smarty 4X P)

